



Description of encryption

1. When you use encryption for the first time, check Option “**Turn on Check Password**” and key in both the account No. and the password for the initial value to start the operation.

Account No. and the password for the initial value

Account No.: USER

Password: 0000




To key in the account No. for first-time use,
please key in USER

To key in the password for first-time use, please
key in 0000

2. After starting the function of encryption, when you read track messages or set GPS, Photo Tagger will ask you to key in the account No. and password before starting and use all features on Photo Tagger.
3. By keying in incorrect account No. and password, a warning message would pop out from Photo Tagger as shown below to remind you.



4. 821E allows you to set your own account No. and password and before using this feature, be sure that encryption is on; only by having encryption on and setting it on the inner page, you would have the push button "**Set Password**" for you to make revisions.



Password

Old User Name:

Old Password:

New User Name:

New Password:

Confirm New Password:

To key in the old account No. for first-time use, please key in **USER**


To key in the old password for first-time use, please key in **0000**

Key in the new account No.

Key in the new password.

Key in the new password one more time.

- If you forget your account No. or password, click directly the push button “**Reset Device**” and upon successful setting of GPS, the account No. and the password will be reset in the initial value, that is to say, being the account No. **USER** and the password **0000**.



[Remark] When resetting GPS, your recording tracks will be automatically erased and the device will be set in the default given in the factory.