






# PLC-200 INSTALLATION GUIDE



PLC-200



Down-Converter



3m at least

Note 1 : use the antenna as high gain as possible.

Note 2 : If the head-end antenna is separated for down stream and up stream, please

Have polarization of two antennas vertical and horizontal respectively.